




**Note:** Connect Sensor shield to braided part of trigger cable.



**Figure C14.1** - 5 Cyl Audi Quattro Crank Angle Sensor

**Figure C14.2** - 5 Cyl Audi Quattro Crank Angle Sensor