



Note 1

Red
Black

Green
Purple

Not Connected

White

Orange

Black

Red

Ignition Switch

Battery +

Coil

To Distributor

M4 - ECU

IGN 1

33

Setup	ign	2
	COIL	1
	dELL	0

Note 1

Twist the Red and Black wires together

Connect the Red Power Wire to the heavy battery wire at the starter motor solenoid

Connect the Black Wire to the Engine Block near the starter motor

MoTeC

Title **MSD 6A CDI (M4 ECU)**

Sheet No

Drawing No

Date 19/8/1994

Drawn TW

App

Rev A

M4

M18